



## UV light box for watch glazing

The UV lamp with low heat generation is used for rapid curing of UV adhesives when mineral and sapphire glasses are inserted. The box offers space for up to 3 watches.

Scope of delivery		Nº
<ul style="list-style-type: none"><li>• UV lamp with timer</li><li>• 4 fluorescent tubes with 9 W each</li></ul>	220 – 240 V	321651

1. Plug the unit into the mains supply.
2. Use the round rocker switch on the back of the unit to set the desired operating time:

### Timer off

Rocker switch straight

→ 30 minutes continuous operation

### Timer on

Rocker switch tilted upwards

→ 90 seconds operating time

Rocker switch tilted down

→ 120 seconds operating time

3. Insert a maximum of 3 watches into the device at the same time.
4. Turn on the unit by pressing the power switch left on the rear panel.
5. Repeat step 4 if necessary, depending on the curing time of the particular adhesive.



Power switch

Rocker switch for setting the timer

## Important

For best results, replace the neon tubes every 6 months.

Avoid direct eye contact with the neon tubes when in use! The tubes comply with CE light intensity standards, however caution is recommended!